



## Instructions for use

OVEN

OCS8487S / BO4CS2F3-42

OCS8487A / BO4CS2F3-42

OCS8687S / BO6SA2F3-42

OCS8687A / BO6SA2F3-42

**Pictograms used**



Important information



Tip

# YOUR OVEN

## ***Your oven***

Introduction	4
Control panel	5
Description	6
Guide rails	7
Telescopic guide rail	8
Door switches	8
Cooling fan	8
Main functions	8
Keys	10
Navigation	11

## ***Initial use***

What to do first	13
------------------	----

## ***Operation***

Selecting your function	16
Functions settings mode	16
Progress mode	18
Finish display	18
Changing settings during the progress	19

## ***Use***

Functions table	20
Steam function	25
Steam tables	28
Culisensor	31
Settings menu	33
Plus menu	34
Cooking information	35
Fast preheat	36
Delayed start	36
Gratin	37
Stage cooking	37
Go to manual cooking	38
Programs and Favourites	39
Egg timer	39
Child lock	40
Warming	40
Defrost	40

## ***Cleaning***

Cleaning the appliance	41
Steam clean	41
Cleaning the Water Tank Filter	42
Descaling	42
Removing and cleaning the guide rails	43
Replacing the oven light bulb	43
Removing the oven door	44
Removing the oven door glass	45

## ***Solving problems***

General	47
---------	----

## ***Your oven and the environment***

Disposing of the appliance and the packaging	49
--	----

### *Introduction*

---

Congratulations on choosing this ASKO steam oven.

This product is designed to offer simple operation and optimum user-friendliness. The oven has a wide range of settings, enabling you to select the correct cooking method every time.

This manual shows how you can best use this oven. In addition to information about operating the oven, you will also find background information that may be useful when using the appliance.



**Please read the separate safety instructions carefully before using the appliance!**

**Read this manual before using the appliance and keep it in a safe place for future use.**

Installation instructions are supplied separately.

# YOUR OVEN

## Control panel



1. Function knob (in 'Off' position)
2. Defrost
3. Programs & Favourites
4. Fast preheat
5. Oven
6. Steam
7. Combi steam
8. Warming
9. Steam clean
10. Display
11. Selection knob
12. On/off key and stop key (cancel)
13. Light key
14. Timer key
15. Navigation key left\*
16. Navigation key right\*
17. Plus key
18. Water reservoir key
19. Confirm key

\* pressing 15+16 activates Child lock




### Note:

The keys respond best if you touch them with a large area of your fingertip. Every time you press a key during use, a short acoustic signal will sound.




## YOUR OVEN

### Description



1. Control panel
2. Water reservoir cover
3. Oven levels
4. Oven door
5. Door handle




### The following accessories are supplied with your oven:



- **Baking tray;** to be used for pastries and cakes.
- **Deep Baking Tray (OCS86 only);** to be used for roasting meat and baking moist pastry. It can also be used as a drip tray. Place the deep baking tray into the first level for use as a drip tray during grilling.
- **Oven rack;** to be used for grilling. A dish or pan with food can also be placed on the oven rack.

*The oven rack is equipped with a safety peg. Lift the rack slightly at the front to slide it out of the oven.*


## YOUR OVEN



- **Non-perforated steam dish;** 40 mm deep (useful for collecting moisture during steaming).
- **Perforated steam dish;** 40 mm deep (useful for steam setting).
  - The steam dishes can be used simultaneously on two levels (i.e. the non perforated steam dish on level 1 and the perforated steam dish on level 2).
  - For steaming you can place the 'perforated steam dish' in the 'non-perforated steam dish'. These can only be used together on a level with telescopic guiderails.
  - **Note: at the steamdishes, discolouration can occur at temperatures above 180 °C! This will not influence proper function of the oven.**
- **Culisensor;** can be used to measure the core temperature of the dish. When the desired temperature is reached, the cooking process will be stopped automatically.

### Guide rails

- The oven has four or five shelf levels, depending on the model. Level 1 is mainly used in combination with bottom heat. The upper two levels are used mainly for the grill function.
- Place the oven rack or baking tray in the gap between the guide rail sliders.



### Telescopic guide rail

One or two shelf levels have fully-retractable telescopic guide rails, depending on the model.

- Pull the telescopic guide rails out of the oven cavity completely and place the oven rack or baking tray. Then slide the oven rack or baking tray, on the telescopic guide rails, back into the oven cavity.

# YOUR OVEN



Only close the oven door once the telescopic guide rails are returned completely back into the oven cavity.

## Door

- The door switches interrupt the operation of the steam oven when the door is opened during use. The oven continues operating when the door is closed.
- This oven has a ‘Soft close door system’. When closing the oven door, this system dampens the movement, from a certain angle, and silently closes the oven door.

## Cooling fan

The appliance is equipped with a cooling fan that cools the casing and control panel.







## Main functions

With the function knob you can select the main functions of your oven.

Setting	Description
	<b>Off/standby mode</b>
	<b>Oven</b> Hot air Hot air + bottom heat Bottom + top heat Large grill Grill Large grill + fan Upper heat Bottom heat Bottom heat + fan Pro roasting Eco hot air
	<b>Fast preheat</b>












# YOUR OVEN


	<b>Programs and favourites</b> Favourites Programs
	<b>Defrost</b> Manual defrost
	<b>Steam</b> Steam Low temperature Sous vide
	<b>Combi steam</b> Hot air + steam density 1 Hot air + steam density 2 Hot air + steam density 3
	<b>Warming</b> Regenerate Plate warming Keep warm
	<b>Steam clean</b>

## Keys


In the table below you can find the discription of the different keys.

Keys	Description of the keys
	<b>Stop key:</b> <ul style="list-style-type: none"> <li>- Press short: cancel operation or go one step back in the menu.</li> <li>- Press long: turn the appliance off or on.</li> </ul>
	<b>Light key:</b> <ul style="list-style-type: none"> <li>- To turn the cavity light on or off.</li> </ul>
	<b>Egg timer</b> <ul style="list-style-type: none"> <li>- The egg timer can be used independent of the oven function.</li> <li>- The longest possible timer setting is 23:59.</li> </ul>
	<b>Navigation key left</b> <ul style="list-style-type: none"> <li>- To move the active area to the left.</li> </ul>
	<b>Navigation key right</b> <ul style="list-style-type: none"> <li>- To move the active area to the right.</li> </ul>
	<b>Plus key</b> <ul style="list-style-type: none"> <li>- To open or exit the settings menu (in standby-mode).</li> <li>- To open or exit the plus menu with the extra options possible at that moment (in on-mode).</li> </ul>
	<b>Child lock</b> <ul style="list-style-type: none"> <li>- Press and hold the left navigation key and right navigation key simultaneously to lock the appliance.</li> </ul>
	<b>Water reservoir key</b> <ul style="list-style-type: none"> <li>- To open the water reservoir hatch.</li> </ul>
	<b>Confirm key</b> <ul style="list-style-type: none"> <li>- To confirm all the white settings/elements in the screen.</li> </ul>

## Navigation



By turning the function knob away from the 0-position, the icon of the chosen main function is lit. The display will show the icon and name of the activated function for about 1,5 seconds. Next you will see the chosen main function and sub-function at the top of the display in the feedback bar. Also the function settings mode will become active (grey background). In this activated area you can select your settings using the selection knob.



### Within every menu the navigation is as follows:

- Use the navigation keys or press the selection knob to move the active area (grey background).
- The setting in the active area can be changed by turning the selection knob (left = decrease, right = increase). The setting will be saved automatically.
- When all elements in the screen are set, then confirm these settings by pressing the confirm key (this key will start blinking when it is possible to start the program).
- Press the stop key to go one step back in the menu.

## YOUR OVEN



At the top of the display is a feedback bar. This bar shows where you are in the menu and what setting you are changing. Functions / settings are separated with a vertical line.

SETTINGS | GENERAL | SOUND | KEY SOUND


### What to do first

- Clean the oven interior and accessories with hot water and washing-up liquid. Do not use aggressive cleaning agents, abrasive sponges and similar.
- The oven will emit a particular odor when it is used for the first time; this is normal. Make sure that there is good ventilation during initial use.



When the appliance is plugged in for the first time or after the appliance was disconnected from the mains for a longer period of time, you have to set 'Language', 'Date', 'Time' and 'Water hardness'.

### Setting the language



In case you are not comfortable with the language on the display, you can select another language. The default setting is 'English'.

1. Turn the selection knob and select your preferred language from the displayed list.
2. Confirm the setting by pressing the confirm key.  
*The next screen will be displayed.*

### Setting the date




1. Turn the selection knob and change the first setting (Day).
2. Confirm this setting by pressing the right navigation key or by pressing the selection knob.
3. Turn the selection knob and change the next setting (Month).
4. Confirm this setting by pressing the right navigation key or by pressing the selection knob.
5. Turn the selection knob and change the last setting (Year).
6. Confirm this setting by pressing the confirm key.  
*The next screen will be displayed.*

### Setting the time



1. Turn the selection knob and change the hours.
2. Confirm this setting by pressing the right navigation key or by pressing the selection knob.
3. Turn the selection knob and change the minutes.
4. Confirm this setting by pressing the confirm key.

### Setting the water hardness



The water hardness must be set prior to initial use.

If the water is softer or harder than the default setting, you can alter the set hardness level.

### Checking the water hardness

You can measure water hardness using the 'paper test strip' supplied with your appliance. For information about water hardness in your region please contact your local water board.

### Using the 'paper test strip'

Dip the test strip in water for 1 second. Wait 1 minute and read the number of bars on the paper strip. Check the table for the correct water hardness setting.

### Setting the water hardness

1. Compare the test strip with the image on the display.
2. Turn the selection knob until the bars on the screen correspond with those on the test strip.
3. Press the confirm button to save the set water hardness.

*The equipment has now been programmed so that the descaling notification will appear in accordance with the actual water hardness.*

## INITIAL USE

Display	Test strip number/colour of the bars	Type	PPM	French hardness (°df)	German hardness (°dH)
1	4 green bars	Very soft water	0 - 90	0 - 9	0 - 5
2	1 red bar	Soft water	90 - 178	9 - 18	5 - 10
3	2 red bars	Rather hard water	178 - 267	18 - 26	10 - 15
4	3 red bars	Hard water	267 - 356	26 - 35	15 - 20
5	4 red bars	Very hard water	> 356	> 35	> 20

*All the start-up settings are now set and the display will show the standby screen. The appliance is now ready for use.*




The language, time, date and water hardness can be adjusted in the settings menu (see 'Settings menu' chapter). The settings menu can be opened from the start display via the 'Plus' menu.

### Standby display

The standby display will show the time, date, cavity temperature (if this is higher than 80 °C) and the timer (if set). The appliance goes to standby mode after:

- Turning the function knob to 0 ('off' position).
- Pressing the stop key multiple times (deeper in the menu).



### Off mode

- Default the appliance will shut down after no action for a set time of 30 minutes.
- Press and hold the stop key to shut down the appliance manually.

### Switching on the appliance

- Press and hold the stop key to switch on the appliance.
- The appliance can also be switched on by turning the function knob to a function.

## Selecting your function

Select a function appropriate for the meal you are cooking. Consult the table in chapter 'Functions table' to see which functions are available.

- Go directly to the progress mode by pressing the confirm key (this key is blinking if it is possible to start the program).


After you have chosen a main function, the function settings mode is active (grey background). In this activated area, it is now possible to change the settings in this function.

## Function settings mode

**Example** (Oven/Hot air + bottom heat/40 minutes)

1. Choose a main function by turning the function knob.


*The first sub-function setting becomes active.*



Now the settings can be changed as desired. There is the possibility to set:

- The function (consult the table in chapter 'Functions table').
- The temperature.
- The time.

2. Turn the selection knob and change the setting.




3. Confirm the setting by pressing the right navigation key or by pressing the selection knob.

*The next sub-function setting becomes active.*




4. Turn the selection knob and change the setting.






5. Confirm the setting by pressing the right navigation key or by pressing the selection knob.

*The next sub-function setting becomes active.*



- The timer icon shows that there is no timer necessary for this function. Press the confirm key to start the program directly with the chosen settings (see step 7).
- To set the timer, go to step 6.
- If there is a timer necessary for a current function, the default timer setting is displayed instead of the timer icon.


6. Turn the selection knob and change the setting.



- H:M notation.


7. If preferred, select any additional setting using the plus menu (for example fast preheat). See for more information chapter 'Plus menu'.
8. If the chosen function involves steam, then the tank must be filled with clean water before starting the program.
9. Start the program: press the confirm key to go to the progress mode.

*The program will start with the chosen settings; the oven will go to the progress mode and the progress screen is shown.*




## Progress mode

- Left side on the screen, the temperature is displayed (if the set temperature is not reached, the temperature will switch between cavity temp (grey) and set temp (white)). If the set temperature is reached a pop-up will appear 'set temperature is reached'.
- Right side on the screen, the time (counting down) or the progress time (counting up if no time was set) is displayed. Next to the cooking time you can see the finishing time.



- If preheating is chosen, the progress mode will first show the preheating display (preheating in the feedback bar and the preheating icon). All settings are displayed only the colours are switched. The cavity temperature is white and the chosen settings are grey. If the set temperature is reached, a pop-up will appear: 'Set temperature is reached. Insert dish'.



## Finish display

When the timer is finished, the 'finish display' will appear. Now it is possible to:

- Stop the progress.
- Add extra time.
- Gratin (if applicable).
- Save as favourite.



### **Stop the progress**

1. Press the confirm key.

*The finish display will be closed and the standby screen will be shown.*

- If there is no action within 10 minutes, the display will switch to standby mode.

### **Add extra time**

1. Press the right navigation key to select 'Add extra time'.
2. The time setting becomes active and can be changed directly by rotating the selection knob.
3. Confirm by means of the confirm key.  
*The previous process is activated again.*

### **Gratin**

1. Press the right navigation key to select 'Gratin'.  
*Grill settings will be shown.*
2. The temperature (default 200 °C) and time can be set or the program can be started directly by pressing the confirm key (time will start counting up).  
*After confirmation with the confirm key the progress screen will be shown.*

### **Save as favourite**

1. Press the right navigation key to select 'Save as favourite'.  
*The next screen will show 10 positions where the program can be positioned.*
2. Select a position for your recipe by rotating the selection knob and press the confirm key to save it.
3. Give the recipe a name. Rotate the selection knob to select the appropriate letter and press the selection knob to confirm and go to the next letter.
  - You can delete a character by means of the backspace function in the character list (arrow).
4. Press the confirm key to save the recipe.

## **Changing settings during the progress**

- During progress, pressing the navigation keys will show the active area. The selected setting can now be changed, see chapter 'Function settings mode'.
- After confirmation with the confirm key the progress screen will be shown with the changed settings.
- After 5 seconds without actions the progress settings are cancelled and the display will return to the progress screen.







**Functions table**









Consult the table to choose the desired function. Also consult the instructions for preparation on the dish packaging.

















- **Only use glass dishes that can withstand temperatures of 230 °C.**

Function	Description	
<b>Oven functions</b>		
	<p><b>Hot Air</b></p> <ul style="list-style-type: none"><li>• Heating by means of hot air from the back of the oven.</li><li>• This mode provides uniform heating and is ideal for baking.</li><li>• Place the baking tray or oven rack on level 2.</li><li>• Suggested temperature: 180 °C</li><li>• Preheating is recommended.</li></ul>	
	<p><b>Hot Air + Bottom Heat</b></p> <ul style="list-style-type: none"><li>• Heating by means of hot air from the back of the oven and the bottom heating element.</li><li>• This mode can be used to bake pizza, moist pastry, fruitcakes, leavened dough and short crust.</li><li>• Place the baking tray or oven rack on level 2.</li><li>• Suggested temperature: 200 °C</li><li>• Preheating is recommended.</li></ul>	
	<p><b>Top + Bottom Heat</b></p> <ul style="list-style-type: none"><li>• Heating by means of the upper and lower heating elements.</li><li>• This mode can be used for traditional baking and roasting.</li><li>• Place the baking tray or oven rack on level 2.</li><li>• Suggested temperature: 200 °C</li><li>• Preheating is recommended.</li></ul>	




Function	Description	
	<p><b>Large Grill</b></p> <ul style="list-style-type: none"> <li>• Heating by means of the upper element and grill element.</li> <li>• This mode can be used with dishes and baked goods that require a distinctive bottom crust or browning. Use just before the end of the baking or roasting time.</li> <li>• Place the the oven rack on level 4 and the baking tray on level 2.</li> <li>• <b>Maximum allowed temperature: 230 °C</b></li> <li>• Monitor the cooking process at all times. The dish may burn quickly due to the high temperature.</li> <li>• Preheating is recommended.</li> </ul>	
	<p><b>Grill</b></p> <ul style="list-style-type: none"> <li>• Heating by means of the grill element.</li> <li>• This mode can be used for grilling a smaller amount of open sandwiches, beer sausages, and for toasting bread.</li> <li>• Place the oven rack is on level 4 and the baking tray on level 2.</li> <li>• <b>Maximum allowed temperature: 230 °C</b></li> <li>• Monitor the cooking process at all times. The dish may burn quickly due to the high temperature.</li> <li>• Preheating is recommended.</li> </ul>	
	<p><b>Large grill + Fan</b></p> <ul style="list-style-type: none"> <li>• Heating by means of the top heating elements. The heat is distributed by the fan.</li> <li>• This mode can be used for grilling meat, fish and vegetables.</li> <li>• Place the oven rack on level 4 and the baking tray on level 2.</li> <li>• Suggested temperature: 170 °C</li> <li>• Monitor the cooking process at all times. The dish may burn quickly due to the high temperature.</li> <li>• Preheating is recommended.</li> </ul>	

Function	Description	
	<b>Top Heat</b> <ul style="list-style-type: none"> <li>• Heating only by means of the upper heating element.</li> <li>• This mode can be used when you wish to bake/roast the top part of your dish.</li> <li>• Place the baking tray or oven rack on level 2.</li> <li>• Suggested temperature: 150 °C</li> </ul>	
	<b>Bottom Heat</b> <ul style="list-style-type: none"> <li>• Heating only by means of the lower heating element.</li> <li>• This mode can be used with dishes and baked goods that require a distinctive bottom crust or browning.</li> <li>• Place the baking tray or oven rack on level 2.</li> <li>• Use just before the end of the baking or roasting time.</li> <li>• Suggested temperature: 160 °C</li> </ul>	
	<b>Bottom Heat + Fan</b> <ul style="list-style-type: none"> <li>• Heating by means of the lower heating element. The heat is distributed by the fan.</li> <li>• This mode can be used for baking low leavened cakes, as well as for preservation of fruit and vegetables.</li> <li>• Place a not too high baking tray on level 2, so that hot air can also circulate over the upper surface of the food.</li> <li>• Suggested temperature: 180 °C</li> </ul>	
	<b>Pro Roasting</b> <ul style="list-style-type: none"> <li>• Heating by means of the upper heating element in combination with the grill heating element and hot air.</li> <li>• This mode can be used for roasting all types of meat.</li> <li>• Suggested temperature: 180 °C</li> </ul>	

Function	Description	
	<b>ECO Hot air</b> <ul style="list-style-type: none"> <li>• Heating by means of hot air. ECO hot air uses less energy but gives the same result as the hot air setting. Cooking takes a few minutes longer.</li> <li>• This mode can be used for roasting meat and baking pastry.</li> <li>• Place the tray on level 2.</li> <li>• Suggested temperature: 180 °C</li> <li>• This setting makes use of the residual heat (heating is not on the whole time) to achieve low energy consumption (in accordance with energy class EN 60350-1). In this mode the actual temperature in the oven is not displayed.</li> </ul>	
<b>Steam functions</b>		
	<b>Steam</b> <ul style="list-style-type: none"> <li>• Heating by means of steam.</li> <li>• See chapter 'Steam function' for more information.</li> <li>• Steam of 100 °C is sprayed into the oven cavity at regular intervals.</li> <li>• This mode can be used to steam vegetables, eggs, fruit and rice, for example.</li> </ul>	
	<b>Steam - Low temperature</b> <ul style="list-style-type: none"> <li>• Heating by means of steam.</li> <li>• See chapter 'Steam function' for more information.</li> <li>• Steam is sprayed into the oven cavity at regular intervals.</li> <li>• This menu can be used to steam vegetables and fish, to keep food warm and defrost food.</li> </ul>	
	<b>Sous vide</b> <ul style="list-style-type: none"> <li>• Heating by means of steam.</li> <li>• See chapter 'Steam function' for more information.</li> <li>• The vacuum-sealed food is slow-cooked at a low temperature.</li> <li>• With this method the food's flavour, vitamins and minerals are preserved. Vacuum sealing gives the dish a longer shelf life.</li> <li>• Use this function to cook vegetables, fruit, meat, poultry and fish.</li> </ul>	

Function	Description	
<b>Combi steam functions</b>		
 High 3  Medium 2  Low 1	<p><b>Hot air + Steam density 1 / 2 / 3</b></p> <ul style="list-style-type: none"> <li>• Heating by means of hot air in combination with steam.</li> <li>• The steam is sprayed into the oven cavity at regular intervals.</li> <li>• This mode can be used for baking types of pastry such as puff pastry, brioche pastry, yeast dough buns, French bread, gratins and roasting meat. The hot steam ensures a nice crispy brown top and an airy texture. Meat and fish remain nice and juicy inside. For this mode always make sure that the water reservoir is filled with fresh water.</li> <li>• HIGH: cooking escalopes, steaks and smaller chunks of meat</li> <li>• MEDIUM: reheating cool/frozen meals, cooking fish fillets and vegetables au gratin</li> <li>• LOW: cooking large chunks of meat (roast, whole chicken), baking risen dough (bread and rolls), cooking lasagna etc.</li> </ul>	
<b>Extra functions</b>		
	<p><b>Warming</b></p> <ul style="list-style-type: none"> <li>• Plate warming: this function is used for warming tableware, so that the served food stays hotter for longer.</li> <li>• Keep warm: this mode is used to keep already cooked dishes warm.</li> <li>• Regenerate: this mode is used to warm already cooked dishes. The use of steam means there is no loss of quality. Taste and texture are preserved as though the dish is freshly-cooked. Various dishes can be regenerated simultaneously.</li> </ul>	
	<p><b>Steam clean</b></p> <ul style="list-style-type: none"> <li>• With this function and a damp cloth, you can easily remove grease and dirt from the oven walls.</li> <li>• Use this function only when the oven has cooled down fully. Steam is sprayed into the oven cavity at regular intervals.</li> <li>• After soaking, food residues can be removed using a damp cloth.</li> </ul>	



Function	Description	
	<b>Defrost</b> <ul style="list-style-type: none"><li>• With this function, the air circulates by means of the fan. The air will be heated to a temperature of 30 °C.</li><li>• Use this function to defrost frozen dishes.</li></ul>	
	<b>Programs and Favourites</b> <ul style="list-style-type: none"><li>• Programs: for baking and roasting. Select a dish from a list of pre-programmed dishes.</li><li>• Favourites: Select your own stored recipes.</li></ul>	
	<b>Fast preheat</b> <ul style="list-style-type: none"><li>• With this function, the oven cavity is quickly heated to the desired temperature. Do not use this setting when you have a dish in the oven.</li></ul>	

*Steam function*

**Steam cooking**

Healthy and natural, steam cooking retains the colour and taste of the dish. No odors are released using this cooking method.  
It is not necessary to add salt or extra herbs to the water in the reservoir.



**Note:** The water system empties each time the steam function is finished. This action is audible and is part of the steam oven's normal operation.

**Advantages of steam cooking**

- Steam cooking (stewing, cooking, roasting) starts before the oven cavity temperature reaches 100 °C.
- Slow cooking (stewing, cooking, roasting) is also possible at lower temperatures. It is healthy: vitamins and minerals are preserved as only a small proportion of these dissolve in the hot moisture of the dish.
- It is not necessary to add any form of fat or oil during steam cooking.
- Steam retains the taste of the dish.
- Steam does not distribute smell or taste, enabling meat or fish to be cooked together with vegetables.
- Steam is also suitable for blanching, defrosting and warming or keeping a dish warm.

## **Sous vide**

Using the sous vide steam function:


- Vacuuming
  - ▷ First vacuum the food in plastic using a vacuuming machine. This process removes most of the air from the plastic bag. The bag preserves nutrients and taste during cooking, resulting in food that is juicier, softer and tastier.
- Vacuum cooking
  - ▷ Cook the dish at the correct temperature and the correct time using the oven's Sous Vide steam setting (see 'Recipes and cooking times').
  - ▷ Most dishes can be kept at serving temperature (around 60 °C) for a few hours, which makes mise en place very easy: you simply remove the dish from the oven when you need it.

## **Filling the water reservoir**

Always fill the reservoir prior to using a steam function.

Use clean and cold tap water, bottled water without added minerals or distilled water suitable for consumption.

1. Press the 'water reservoir' key to open the water reservoir cover.
2. Use the handle to remove the reservoir from the oven.
3. Remove the water reservoir lid and clean the water reservoir with clean water.
4. Fill the reservoir with water up to the 'MAX' mark on the reservoir (around 1.2 litres).
5. Push the water reservoir back in the oven until a click is heard (position switch is activated).
6. Close the water reservoir cover.



*Any water remaining in the steam system after cooking will be pumped back into the water reservoir. Empty, clean and dry the water reservoir after using the steam function. Only fill the reservoir just prior to using it!*

## Steam tables

### Steam and Low temperature steam

Use the settings and times in this table as guide lines for steaming.

Always fill the water tank with fresh water to the maximum level.

Dish	Temperature	Time (min.)	Accessory (shelf level)
Broccoli Florets	100 °C	12 - 16	Perforated steam dish (2)
Whole Carrots	100 °C	25 - 30	Perforated steam dish (2)
Sliced Vegetables (pepper, courgettes, carrots, onions)	100 °C	15 - 20	Perforated steam dish (2)
Green Beans	100 °C	20 - 25	Perforated steam dish (2)
Asparagus	100 °C	15 - 20	Perforated steam dish (2)
Whole Vegetables (artichokes, whole cauliflower, corn on the cob)	100 °C	25 - 35	Perforated steam dish (2)
Peeled Potatoes (cut into quarters)	100 °C	25 - 35	Perforated steam dish (2)
Fish Fillet (2 cm thickness)	80 °C	15 - 20	Perforated steam dish in a non-perforated steam dish (2)
Prawns (raw/uncooked)	100 °C	10 - 14	Perforated steam dish in a non-perforated steam dish (2)
Chicken Breast	100 °C	23 - 28	Perforated steam dish in a non-perforated steam dish (2)
Boiled Eggs (hardboiled)	100 °C	15 - 20	Non-perforated steam dish (2)
Frozen Yeast Dumplings	100 °C	25 - 30	Perforated steam dish (2)
White Rice (basmati or pandan) (add double quantity of water)	100 °C	30 - 35	Non-perforated steam dish (2)
Fruit Compote (use a flat round glass pyrex, add 1 teaspoon sugar and 2 tbsp. water)	100 °C	25 - 35	Baking tray or oven rack (2)
Flan/Crème (6 dessert dishes, each 100 ml, cover dishes with foil)	90 °C	20 - 30	Baking tray or oven rack (2)
Egg Custard (use a large flat glass pyrex dish, cover dish with foil)	90 °C	30 - 40	Baking tray or oven rack (2)

**COMBI: Hot air + Steam level 1, 2, 3**

Use the settings and times in this table as guide lines for baking and roasting. Always fill the water tank with fresh water to the maximum level.

Dish	Temperature	Steam level	Time (min.)	Accessory (shelf level)
Puff Pastry Stripes (add grated cheese)	200 °C	1	15 - 20	Baking tray (1)
Croissants (all ready made croissant dough)	180 °C	1	17 - 23	Baking tray (1)
Homemade Bread	180 °C (preheating)	2	30 - 40	Oven rack (1)
Vegetable Gratin / Potato Gratin	160-180 °C	2	35 - 50	Oven rack (2)
Roast Beef, 1 kg Medium-welldone	1st stage: 180 °C 2nd stage: 180 °C (preheating)	3 3	1. stage: 25 - 35 2. stage: 25 - 35	Oven rack (2) / Baking tray (1)
Oven Fish	200 °C	3	20 - 25	Oven rack (2) / Baking tray (1)
Whole Chicken	1st stage: 210 °C 2nd stage: 210 °C	3	1. stage: 30 - 40 2. stage: 20 - 30	Oven rack (2) / Baking tray (1)
Chicken Pieces	1st stage: 210 °C 2nd stage: 210 °C	3	1. stage: 20 - 30 2. stage: 20 - 30	Oven rack (2) / Baking tray (1)

- Preheating is recommended.
- Turning over the dish is recommended between 1st stage and 2nd stage.
- If you open the door while oven is operating, the oven pauses the program. Close the door to resume the program.

### ***Sous Vide table***


Sous Vide cooking is cooking vacuum-packed food at low constant temperature over a long period of time.

<b>Dish</b>	<b>Temperature</b>	<b>Time (min.)</b>	<b>Accessory (shelf level)</b>
Beef fillet medium (4 cm thickness)	60 °C	110 - 120	Oven rack (2)
Beef fillet well done (4 cm thickness)	65 °C	90 - 100	Oven rack (2)
Lamb rare (3 cm thickness)	60 °C	180 - 190	Oven rack (2)
Lamb medium (3 cm thickness)	65 °C	105 - 115	Oven rack (2)
Chicken breast boneless (3 cm thickness)	70 °C	70 - 80	Oven rack (2)
Duck boneless (2 cm thickness)	70 °C	75 - 85	Oven rack (2)
Turkey boneless (2 cm thickness)	70 °C	75 - 85	Oven rack (2)
Sea bass (4 fillets/1 cm thickness)	70 °C	25	Oven rack (2)
Cod fish (2 fillets/2 cm thickness)	65 °C	70 - 75	Oven rack (2)
Scallops (big size)	60 °C	100 - 110	Oven rack (2)
Mussels with shell	95 °C	20 - 25	Oven rack (2)
Prawns without shell (big size)	75 °C	26 - 30	Oven rack (2)
Octopus	85 °C	100 - 110	Oven rack (2)
Trout fillet (2 fillets/1,5 cm thickness)	65 °C	55 - 65	Oven rack (2)
Salmon fillet (3 cm thickness)	65 °C	100 - 110	Oven rack (2)
Asparagus green (whole)	90 °C	40 - 50	Oven rack (2)
Asparagus white (whole)	90 °C	50 - 60	Oven rack (2)
Courgette (slices of 1 cm)	90 °C	35 - 40	Oven rack (2)
Egg plant (slices of 1 cm)	90 °C	30 - 35	Oven rack (2)
Carrots (slices of 0,5 cm)	95 °C	35 - 45	Oven rack (2)

## Culisensor

If the culisensor is plugged in, the culisensor screen will be shown and a small culisensor icon will appear next to the time. The oven operates until the food core reaches the set temperature. The core temperature is measured by means of the temperature probe.

1. Remove the rubber cap from the socket (right upper corner of the oven cavity).
2. Insert the culisensor plug into the socket and insert the culisensor completely into the dish.



*The display will show the culisensor screen and icon.*

3. Set the function and temperature. Instead of the time, you need to set the core temperature (between 30-100 °C).
4. Start the progress by pressing the confirm key.
  - During cooking, the rising temperature of the core will be displayed (the desired core temperature may be adjusted during the cooking process).
  - When the set core temperature is reached, the cooking process will stop. An acoustic signal will sound, which you may turn off by pressing any key. After one minute, the acoustic signal will be switched off automatically. The current time appears on the display.



**Always place the culisensor's entire metal probe in the dish.**

**Caution! After cooking, place the rubber cap back on the culisensor socket.**



**Only use the probe intended for use with your oven. Make sure the probe does not touch the heating element during cooking. After cooking, the probe will be very hot. Take care to prevent injury (burns).**

**Recommended core temperature values**





<b>Beef</b>		
Fillet/sirloin	medium	55 - 58 °C
Roast beef	medium	55 - 60 °C
Round steak	well-done	85 - 90 °C
Roast beef	well-done	80 - 85 °C
Stewed beef	well-done	90 °C
<b>Pork</b>		
Hoof/leg	well-done	75 °C
Hoof/leg	slightly pink	65 - 68 °C
Pork loin	slightly pink	65 - 70 °C
Pork shoulder	well-done	75 °C
Pork belly/stuffed	well-done	75 - 80 °C
Pork belly	well-done	80 - 85 °C
Roast pork hoof	well-done	80 - 85 °C
Pork hoof	well-done	80 - 85 °C
Cooked ham	very tender	64 - 68 °C
Kassel ribs	well-done	65 °C
Breaded ham		65 - 68 °C
<b>Veal</b>		
Veal loin	slightly pink	58 - 65 °C
Veal hoof/leg of veal	well-done	78 °C
Fried kidneys	well-done	75 - 80 °C
Roast veal/shoulder	well-done	75 - 80 °C
Leg of veal	well-done	75 - 78 °C
<b>Mutton</b>		
Mutton loin	pink	65 - 70 °C
Mutton loin	well-done	80 °C
Mutton hoof	pink	70 - 75 °C
Leg of mutton		82 - 85 °C
<b>Lamb</b>		
Leg of lamb	pink	60 - 62 °C
Leg of lamb	well-done	68 - 75 °C
Lamb loin	pink	54 - 58 °C
Lamb loin	well-done	68 - 75 °C
Lamb shoulder	well-done	78 - 85 °C
<b>Poultry</b>		
Chicken	well-done	85 °C
Goose/Duck	well-done	90 - 92 °C
Turkey	well-done	80 - 85 °C
<b>Pastries etc</b>		
Pastries		72 - 85 °C
Terrines		60 - 70 °C



Fish		
Salmon	soft	60 °C
Fish fillet		62 - 65 °C
Entire fish		65 °C
Terrine		62 - 65 °C

## Settings menu

The settings menu is only available by pressing the 'plus key' when the appliance is in standby mode.

Setting	Description
	<b>General</b> Language Time Date Sound
	<b>Display</b> Brightness Clock size Night mode Appliance to stand-by mode
	<b>Cooking</b> Default program intensity Steam Preheat settings
	<b>System</b> Appliance information Factory settings Oven light

### General

You can set the following from this menu:

- Language (language of the display)
- Time (always in 24H format)
- Time display (24H or 12H format)
- Date (always day-month-year format)
- Date display (ddmmyyyy or mmddyyyy)
- Sounds (volume of the general sounds and alarms)
- Key sounds (on/off)
- Welcome sound (startup/shutdown sound on/off)

## Display

You can set the following from this menu:

- Brightness (low, mid, high)
- Night mode (start and end time for lower display brightness: first display set start timer, second display set end time)
- Clock size (small / large)
- Stand-by (auto switch off / manually switch off)



**Changing to manually switch off will increase energy consumption. If the oven is switched off manually (or when an interruption of the power supply occurs) this function will be reset (the display will automatically switch off).**

## Cooking settings

You can set the following from this menu:

- Default program intensity (low / medium / high)
- Steam settings (Water hardness / Descaling)
- Preheat settings (set preheat default on or off)

## System

You can set the following from this menu:
















- Appliance information (request appliance information)
- Factory settings (back to factory settings)
- Oven light (auto switch off after 1 min. / manual)

## Plus menu

---

Depending on the function, there is a possibility to choose extra functionality (after you have chosen a main function and settings in the 'Function settings mode') by pressing the 'plus key'.

- A small icon next to the current time will give an indication about the activated plus menu functions. The colour of the icon will indicate if it is active (white) or inactive (grey).
- To exit the plus menu, press the 'stop key' or 'plus key'; the display will show the previous screen again.
- To cancel an extra functionality, select 'cancel' (icon with a red stripe).

+ Menu	Description	Icon
	<b>Cooking info</b> Request more information about the selected function.	
	<b>Fast preheat</b> Preheat the oven to the desired temperature quickly (not available in combination with delayed start).	
	<b>Delayed start</b> The cooking process will start automatically and will be finished at the preferred time. Only available if a cooking time is set, not available in combination with preheat.	
	<b>Gratin</b> To add the grill function at the end of the progress; gratin time will be added at the end of the progress.	
	<b>Add to favourites</b> To add the settings for the cooked dish to your favourites (see chapter 'Finish display').	
	<b>Stage cooking</b> Combine up to three functions in one cooking process.	
	<b>Go to manual cooking</b> To edit a standard program as stage cooking program.	
	<b>Add steam 1-3x</b> Divide up to three steam cycles evenly over the cooking process. Choose at least 10 minutes cooking time.	
	<b>Add steam</b> Add a steam cycle to the cooking process.	

### Cooking information

The cooking info screen will give more information about the chosen function, like the needed equipment and for what kind of purposes the function is used.

## ***Fast preheat***

---

There are two different ways to use fast preheat:

### **Activate the fast preheat in the settings menu (to be default on or off)**

1. Press the plus key when the appliance is in standby mode. Go to 'Cooking settings' and select if the fast preheat should be default on or off.
2. Press the confirm key.
  - If the fast preheat is set to 'default on' the small preheat icon will be shown to indicate the active preheat function.
  - This option is only available for the oven functions.

### **Activate the fast preheat in the plus menu.**

1. Press the plus key (in the 'Function settings mode').
2. Select 'Fast preheat' by pressing the right navigation key.
3. Press the confirm key to activate fast preheat.

*The small preheat icon will be shown next to the current time.*

  - When preheat is activated, the delayed start will be greyed out, because these functions do not work together.
  - When delayed start is activated preheat will be greyed out.
  - To cancel the preheat: press the confirm key again.

### **Starting with fast preheat**

- If a program is started and it will start with the fast preheat, a pop-up will appear. After 15 sec. the pop-up will automatically disappear. The progress screen will show the fast preheat icon, the time will be greyed out.
- If the set temperature is reached a pop-up will show 'The set temperature is reached. Please insert the dish'. Insert the dish and the program will start automatically on door closing.
  - Pressing the confirm key (without opening the door) keeps the appliance at the set temperature. This situation will remain until the door is opened.

## ***Delayed start***

---

Use the 'delayed start' function to start cooking at a later time, by setting the desired finishing time.

1. Press the plus key (in the 'Function settings mode').

2. Select 'Delayed start' with the right navigation key.
3. Press the confirm key.  
*The display will show the delay start symbol, the cooking time and the end time.*
4. Change the finishing time by turning the selection knob and confirm with the confirm key.  
*A small icon will appear to indicate that the function is active.*
  - To cancel the delayed start: go to 'Delayed start' and select 'cancel delayed start' (a pop-up will appear to confirm the cancellation of the delayed start).
5. Start the program: press the confirm key to go to the progress mode.  
*The function will start automatically at the calculated starting time.*

## Gratin

---

To add the grill function at the end of the progress (gratin time will be added at the end of the cooking process).

1. Press the plus key (in the 'Function settings mode').
2. Select 'Gratin' with the right navigation key.
3. Press the confirm key.  
*A small grill icon will appear next to the current time.*
  - To cancel gratin: select 'cancel gratin' in the plus menu.

## Stage cooking

---

This function allows you to combine up to three functions in one cooking process. Select different functions and settings to compose the cooking process of your preference.

1. Press the plus key (in the 'Function settings mode').
2. Select 'Stage cooking' by pressing the right navigation key.
3. Press the confirm key.  
*A small icon will appear next to the current time. The first stage is already filled with the current settings of the function. If there is no time set, then the default time will be set for the first stage.*
  - For example: the oven mode and hot air 180 °C is selected; the default time of 30 min. will be added to the first stage.
4. To add a stage, choose the second function by pressing the navigation keys or pressing the selection knob.
5. Press the confirm key.  
*The display will switch to the settings screen.*

6. Select the desired function, set the temperature and time.
7. Save the stage and return to the stage cooking overview by pressing the confirm key.
  - If the stop key is pressed the setting will be cancelled and the display will turn to the previous display.
8. If desired, add a third stage. Repeat steps 4, 5, 6 and 7.
9. After confirmation, the display will show the set stages, with an edit and delete icon.
10. If all stages are set according to your wishes, then return to the oven setting screen. Press the 'plus key' to close the plus menu.  
*The display will show the normal oven setting screen with the settings of the first stage (stage 1 icon white).*
11. Start the process by pressing the confirm key.
  - If the stop key is pressed, the stage cooking menu will be closed and the oven will return to the normal mode.

### Go to manual cooking

- In the manual cooking mode, a standard program from the 'Programs and favorites' function can be chosen and edited as in 'Stage cooking' mode.
- By selecting the manual function in the plus menu, a popup will appear: 'Switch to oven mode?'. After confirmation the display will switch to the stage cooking mode if the selected program has more stages.

### Programs and Favourites

#### **Automatic programs**

- You can use 'automatic programs' for baking and roasting by selecting a dish from a list of pre-programmed dishes. First select the type of dish and then the dish itself from the available list.
- All the program categories have a picture. When a dish is selected, the program settings will appear. The name of the dish and the name of the active selection are shown in the text bar.
- In the settings, first a picture of the dish is visible (not editable), the weight (depending on the dish) (if it is editable), the intensity (not always editable) and the cooking time. If necessary, adjust the intensity and/or the weight.

**Favourites** (see chapter 'Finish display')

- You can select your own stored recipes in 'favourites'.
- If there are no saved recipes, a pop-up will appear: 'No saved dishes'.
- The name of the recipe appears in the text bar and the saved oven settings are shown.

## Egg timer

The egg timer can be used independent of the oven function.

1. Press the timer key.
2. Change the time by rotating the selection knob.
  - The longest possible timer setting is 23:59.
3. Confirm the setting by pressing the confirm key.
 

*The egg timer is started.*

  - To cancel the timer, set the time back to 0:00 and confirm by pressing the confirm key
  - To close the egg timer menu, press the timer key or the stop key.
4. When the egg timer goes off, a pop-up will appear with the text 'Egg timer expires' and an acoustic signal will sound. Press the stop key to switch off the signal and close the pop-up menu.
  - The sound will stop automatically after approximately 2 minutes.

## Child lock

The oven's control panel can be locked by means of the Child Safety Lock, to protect the oven against unintended use.

1. Press and hold the left navigation key and the right navigation key simultaneously.
 

*The appliance will go into key lock mode. A pop-up will be shown. After 3 seconds the 'Key lock is active' pop-up will close. The current state of the appliance will be visible.*

  - If the key lock has been activated during a cooking process, the process will keep running.
  - If a key is pressed during key lock, the 'Key lock is active' pop-up will show again.
  - The stop key is still active during lock mode. If the appliance is switched off, the process will stop. To turn the appliance on again, deactivate the key lock mode.
2. To deactivate the key lock mode, press and hold the left navigation key and the right navigation key simultaneously again.

### *Warming*

---

- Regenerate
  - This mode is used to warm already cooked dishes. The use of steam means there is no loss of quality. Taste and texture are preserved as though the dish is freshly-cooked. Various dishes can be regenerated simultaneously.
- Plate warming
  - This function is used when you want to warm tableware (plates, cups) so that the served food stays hotter for longer.
  - For this function you can set the warming-up temperature and duration.
- Keep warm
  - Use this function to keep already cooked food at temperature.
  - For this function you can set the food-warming temperature and duration.

### *Defrost*

---

- This function uses hot air (30 °C). Use this function for slow defrosting of frozen dishes (cakes, biscuits, cookies, bread, bread rolls and frozen fruit).
- For this function you can set the duration.
- Turn the food over after half the defrost time has elapsed; stir the food or break up large pieces if these are frozen together.



### Cleaning the appliance

Clean the appliance regularly to prevent fat and food particles from accumulating, especially on the surfaces of the interior and the exterior, the door and the seal.

- Activate the child lock (to prevent that the appliance is switched on accidentally).
- Clean the exterior surfaces with a soft cloth and warm soapy water.
- Next wipe with a clean, damp cloth and dry the surfaces.
- Remove splashes and stains on the interior surfaces with a cloth and soapy water.
- Next wipe with a clean, damp cloth and dry the surfaces.



- **Attention: Make sure that no water enters the vents.**
- **Never use abrasive cleaning materials or chemical solvents.**
- **Always make sure that the seal of the door is clean. This prevents accumulation of dirt and allows you to close the door properly.**

### Steam clean

With the steam clean function and a damp cloth, you can easily remove grease and dirt from the oven walls.

#### **Using steam clean**

Only use steam clean when the oven has cooled down fully. It is more difficult to remove dirt and grease if the oven is hot.



The steam clean program takes 30 minutes.

Food particles on the enamel walls will be sufficiently soaked after 30 minutes so that they can be removed with a damp cloth.

1. Remove all accessories from the oven.
2. Select the 'Steam clean' function
3. Press the confirm button to start steam clean.





**Please note:** Do not open the door during the cleaning process.

### *Cleaning the Water Tank Filter*

If the water tank filter is dirty, you can clean it under the tap.

1. Remove the suction tube with the filter.
2. Clean it out under the tap and put it back into position.  
Ensure that the filter touches the base of the water tank.



### *Descaling*

During the steam process, there can be an accumulation of mineral deposit in the steam system. This needs to be removed from time to time. You need to carry out this task when the 'Appliance needs descaling' notification is shown. If the appliance is not descaled after three notifications, the steam functions will no longer be available. Use this function only when the oven has cooled down fully. The descaling process comprises descaling and rinsing. Notifications with information and requests for actions will be shown on the display during the process.

1. Pour water mixed with descaling agent into the water reservoir.  
Consult the descaling agent instructions for the correct mixing ratio.
2. Open the 'Settings' menu
3. Select 'Cooking settings'
4. Select 'Steamer settings'
5. Select 'Descaling' to select the function.
6. Press the confirm key to start descaling.

#### **Note**

We advise using NOKALK/DLS for descaling. NOKALK/DLS is an extremely efficient descaling agent based purely on natural, entirely biodegradable ingredients. The solution is non-corrosive, not aggressive and is environmentally-friendly. As well as an effective descaling action, it also has a cleansing and anti-bacterial effect, ensuring that the appliance's internal components are preserved in an optimum hygienic state. Therefore food's good taste is preserved and the appliance's service life is extended.


## CLEANING

- Water is used for the steaming process. Water contains calcium and magnesium. Heat causes the water to condense, leaving a mineral deposit (not harmful to humans).
- If the descaling cycle is interrupted prior to the end of the cycle, the program must be restarted from the beginning.

### Removing and cleaning the guide rails

Use conventional cleaning products to clean the guide rails.

- Remove the screw using a screwdriver.
- Remove the guide rails from the holes in the back wall.



### Replacing the oven light bulb



**The lamp in this household appliance is only suitable for illumination of this appliance. The lamp is not suitable for household room illumination.**


The light bulbs (2x) (halogen G9, 230 V, 25 W) are a consumer items and therefore not covered by warranty. To replace it, first remove the baking tray, oven rack and guide rails.



- **Disconnect the appliance from the power supply by removing the plug from the socket or by switching off the circuit breaker in the fuse box.**
- **Please note: the light bulb can be very hot! Use protection to remove the bulb.**

1. Remove the four screws from the cover panel. Remove the cover panel, the glass and the sealing ring.
2. Remove the faulty halogen lamp and replace it with a new one.
3. Replace the cover panel, the glass and the sealing ring.

**Attention:** The sealing ring needs to fit perfectly in the oven wall recess.




### Removing the oven door



- **Keep your fingers away from the hinges of the oven door. The hinges are spring loaded and can cause injury if they spring back.**
- **Make sure that the hinge latches are applied correctly to lock the hinges.**

#### **Remove the oven door.**

1. Open the door to the fully open position.
2. Lift both hinge latches (A) and pull them towards the oven door (B).  
*The hinges will be locked in the 45° position.*
3. Gently close the door until it reaches a 45° angle.
4. Remove the door by lifting and tilting it towards the oven (C). The hinges need to come out of the slots in the oven.



### **Install the oven door.**


1. Hold the door at an angle of approximately 45° in front of the oven.
2. Insert the hinges into the slots and make sure they are both positioned correctly.
3. Open the door to the fully open position.
4. Lift both hinge latches and move them towards the oven.
5. Gently close the oven door and make sure that it closes correctly.  
*If the door does not open or close correctly, then make sure that the hinges are positioned correctly in their slots.*

### **Removing the oven door glass**

The inside of the glass in the oven door can be cleaned. For this it must be removed from the oven door.

1. Slightly lift (1) and shift (2) the clamps at the lower left and right of the door to release the glass (A).
2. Grab the glass (A) at the bottom and gently lift (3) and shift (4) it to remove it from the upper support.
3. The inner glass (B) (depending on the model) can be removed by carefully lifting (5) and shifting (6) it to removing it from the lower support. Also remove the rubber spacers (C) from the inner glass.

## CLEANING



Install the glass in reverse order.

### *General*

---

If you have problems with your oven, then consult the error overview below. Should the problems persist, then please contact the Customer Services Department.

#### **The food stays raw**

- Check whether the timer has been set and you have pressed the 'confirm key'.
- Is the door closed properly?
- Check whether a fuse has blown or a circuit breaker has been activated.

#### **The food is overcooked or undercooked**

- Check whether the correct cooking time has been set.

#### **The keys do not respond; the display does not respond to the keys.**

- Disconnect the appliance from the power supply for a few minutes (remove the mains plug from the socket or switch the circuit breaker to off); then reconnect the appliance and switch it on.

#### **Power failure can cause the display to reset.**

- Disconnect the appliance from the power supply for a few minutes (remove the mains plug from the socket or switch the circuit breaker to off); then reconnect the appliance and switch it on.
- Set the time again.

#### **There is condensation in the oven.**

- This is normal. Wipe the oven clean after use.

#### **The fan keeps working after the oven is switched off.**

- This is normal. The fan will keep working for a while after the oven is switched off.

#### **Air flow can be felt at the door and the exterior of the appliance.**

- This is normal.

#### **Steam escapes via the door or the vents.**

- This is normal.

**Clicking sounds can be heard when the oven is working, particularly in the defrost setting.**

- This is normal.

**The circuit breaker switches off regularly.**

- Consult a service technician.

**The display gives an error code, ERROR XX ...**

*(XX indicates the number of the error).*

- There is a fault in the electronic module. Disconnect the appliance from the power supply for a few minutes. Then reconnect it and set the current time.
- Consult a service technician if the error persists.

**Storing and repairing the oven**

Repairs should only be performed by a qualified service technician.

If maintenance is required, then remove the mains plug from the socket and contact the ASKO customer service.

**Have the following information to hand when you call:**

- The model number and serial number (stated on the inside of the oven door)
- Warranty details
- A clear description of the problem



**Choose a clean, dry place if you have to store the oven temporarily, as dust and moisture can damage the appliance.**



### Disposal of the appliance and packaging

This product is made from sustainable materials. However, the appliance must be disposed of responsibly at the end of its useful life. The government can provide you with information about this.

The packaging of the appliance can be recycled. The following materials have been used:

- cardboard
- polyethylene wrap (PE)
- CFC-free polystyrene (hard PS foam)

Dispose of these materials responsibly in accordance with legal provisions.



The product has a pictogram of a rubbish bin with a cross through it. This indicates that household appliances must be disposed of separately. This means that the appliance may not be processed via the regular waste flow at the end of its useful life. You should take it to a special municipal waste depot or a sales outlet that offers to do this for you.

Collecting household equipment separately prevents harm to the environment and public health. The materials used in manufacturing this appliance can be recycled, which provides considerable savings in energy and raw materials.



#### **Declaration of conformity**

We hereby declare that our products comply with the relevant European directives, standards and regulations as well as all requirements referred to in the standards.







The appliance identification card is located on the inside of the appliance.

When contacting the service department,  
have the complete type number to hand.

You will find the addresses and phone numbers of the service organisation on the  
guarantee card.

 **ASKO**



551579

en (04-16)